Complete ATCA IPMI Test Suite and Validation or VT027/VT028 Development



ATC001



FIGURE 1: ATCOO1 option load for IPMI Test Suite and Validation

KEY FEATURES

- Capture and store I²C bus data
- Analyzer mode
- Exerciser mode
- Compliance test mode
- Graphical User Interface (GUI)
- Field-upgradable firmware
- Two 10/100 Mbit Ethernet ports routed to the front panel or to zone 2
- Option for VadaTech VT028 for evaluation and testing
- Option for VadaTech VT027 for evaluation and testing
- VT027 option allows four NXP LPC2138's to be programmed at a time
- IPMI 2.0 compliant
- RoHS compliant

VadaTech designed the ATCOO1 simulator in the ATCA form factor to test, capture and validate I²C traffic on the Intelligent Platform Management Bus (IPMB). The ATCOO1 utilizes an integrated VTOO1 IPMI controller to monitor or inject IPMI packets into the shelf. A Graphical User Interface (GUI) validates and displays the IPMI packets or schedules IPMI messages for injection into the shelf. The GUI application communicates with the integrated VTOO1 IPMI controller through an Ethernet port on the front panel or the rear (base channel on Zone 2).

In the Zone 3 area, the ATCO01 has eleven I²C connectors for expansion to other parts of the chassis or external devices. The ATCO01 facilitates creation of a robust test environment and real world simulation.

The ATCO01 can also be loaded with VadaTech VT027 or VT028 IPMI controller based on the NXP LPC2138 Processor. This optional load allows development and evaluation of the VadaTech VT027/VT028 IPMI solution. The VT027 can manage up to eight AMC slots and connects directly to the ATCA IPMI bus while the VT028 is targeted for ATCA modules that don't have any AMC slots.



SPECIFICATIONS

Architecture						
Physical	Dimensions	Width: 12.687in. (322.25 mm)				
		Depth: 11.024 in. (280 mm)				
	IPMI Test Suite and	Analyzer mode				
Туре	Validation Platform	Exerciser mode				
		Compliance test mode				
	VT027	VadaTech VT027 schematic implementation				
Standards						
Module Management	IPMI	IPMI Version 2.0				
Configuration	'					
Power	ATC001	2 Watts				
	Temperature	Operating Temperature: 0° to 65° C				
Environmental		Storage Temperature: -40° to +90° C				
	Vibration	1G, 5-500Hz each axis				
	Shock	30Gs each axis				
	Relative Humidity	5 to 95 percent, non-condensing				
	Interface Connectors	One USB Host port and one USB Device port				
		Three RS-232 ports (DB9)				
Front Panel	(See Ordering Options)	One RS-485 port (DB9)				
		Dual 10/100 Ethernet ports with RJ-45 connectors				
	LEDs	IPMI Management Control				
		Activity and Link				
	Mechanical	Hot Swap Ejector Handle				
Other						
MTBF	MIL Spec 217-F > 221,000 Hrs. (VT027 option)					
Certifications	Designed to meet FCC, CE and UL certifications where applicable					
Standards	VadaTech is certified to both the ISO9001:2000 and AS9100B:2004 standards					
Compliance	RoHS and NEBS					
Warranty	Two (2) years					
Trademarks and Logos	The VadaTech logo is a reg	istered trademark of VadaTech, Inc. Other registered trademarks are the property of their				
	respective owners. Advanc Manufacturers Group. All r	edMC [™] and the AdvancedTCA [™] logo are trademarks of the PCI Industrial Computers ights reserved. Specification subject to change without notice.				

For Use as a Protocol Analyzer:

The ATCOO1 bus analyzer offers the ability to simultaneously monitor up to four I²C buses. The accompanying software interprets and displays the IPMI and ATCA messages, enabling rapid analysis and diagnosis of communication and protocol problems. Important features include:

- AdvancedTCA shelf IPMB-A and IPMB-B monitoring
- External bus support via I²C connectors
- · Configurable Ethernet interface to packet analysis software

The ATCOO1 includes an onboard VTOO1 Intelligent Platform Management Interface (IPMI) controller. This management controller provides four general-purpose I^2C buses, which are routed to the Zone 1 Connector and to a standard I^2C connector.

FIGURE 2: ATCOO1 Functional Block Diagram as Protocol Analyzer option



VadaTech Incorporated • 198 N. Gibson Rd., Henderson, NV 89014 • Tel: (702) 896-3337 • Fax (702) 896-0332 Email: info@vadatech.com • www.vadatech.com FIGURE 3: Viewing a captured trace

The second se	ew Settings latform Event && Request				•	Express	ion Apply	1	
No.	Time	ius	Dir	Src	Dest	Sea	Net En	 Command	
722	77.050.000 IF	PMB-A	REO	0x92	0x20	16	Sensor/Event	Platform Event	
724	77.330.000 IF	PMB-A	REQ	0x88	0x20	1	Sensor/Event	Platform Event	
725	77.410.000 IF	PMB-A	REQ	0x90	0x20	20	Sensor/Event	Platform Event	
728	77.740.000 IF	PMB-B	REQ	0x88	0x20	2	Sensor/Event	Platform Event	
729	77.810.000 IF	PMB-B	REQ	0x92	0x20	20	Sensor/Event	Platform Event	
730	77.830.000 IF	PMB-A	REQ	0x92	0x20	8	Sensor/Event	Platform Event	
731	77.840.000 IF	PMB-B	REQ	0x92	0x20	12	Sensor/Event	Platform Event	
732	77.870.000 IF	PMB-A	REQ	0x92	0x20	16	Sensor/Event	Platform Event	
735	78.210.000 IF	PMB-A	REQ	0x88	0x20	3	Sensor/Event	Platform Event	
736	78.230.000 IF	PMB-B	REQ	0x90	0x20	20	Sensor/Event	Platform Event	
738	78.610.000 IF	PMB-B	REQ	0x88	0x20	4	Sensor/Event	Platform Event	
739	78.640.000 IF	PMB-B	REQ	0x92	0x20	20	Sensor/Event	Platform Event	
740	78.650.000 IF	PMB-A	REQ	0x92	0x20	8	Sensor/Event	Platform Event	
741	78.660.000 IF	PMB-B	REQ	0x92	0x20	12	Sensor/Event	Platform Event	
742	78.690.000	PMB-A	REQ	0x92	0x20	16	Sensor/Event	Platform Event	
743	79.020.000	PMB-A	REQ	0.00	0x20	5	Sensor/Event	Platform Event	
744	79.050.000	PIMB-A	REQ	0×90	0x20	20	Sensor/Event	Platform Event	
795 744	79,430,000	PIME-E	REQ	0,02	0×20	20	Sensor/Event	Platform Event	
1 I	79.460.000	Pirin-n	REO	11X.97	HXZ11	211	hensorievene	Platform Event	
🖂 Re	equest: 0x88 -> 0x20) Platí	orm	Event	(Senso	r/Eve	nt) (seq 2)		
+									
	-Header						, (Deal D)		
	-Header -Body						, (beq b)		
E	- Header - Body - Fvent Message Re	vision		0v04	(4)		, (0.4 0,		
Ē	- Header - Body - Event Message Re	vision	:	0x04	(4)				
	- Header - Body Event Message Re Sensor Type	vision	:	0x04 0x01	(4) (Tempera	ture)	, (
E	- Header - Body - Event Message Re - Sensor Type - Sensor Number	vision	::	0x04 0x01 0x02	(4) (Tempera (2)	ture)	, (
	- Header - Body - Event Message Re - Sensor Type - Sensor Number - Event Type	vision	: : : : : : : : : : : : : : : : : : : :	0x04 0x01 0x02 0x01	(4) (Tempera (2) (Thresho	ture) 1d)	, (
Ē	Header Body Sensor Type Sensor Number Event Type Event Type	vision	: : : : :	0x04 0x01 0x02 0x01 0x01	(4) (Tempera (2) (Thresho (Deasser	ture) 1d) tion)	, (
	- Header - Body - Event Message Re - Sensor Type - Sensor Number - Event Type - Event Direction - Offset	vision	: : : : : : : : : : : : : : : : : : : :	0x04 0x01 0x02 0x01 0x01 0x01	(4) (Tempera (2) (Thresho (Deasser (Upper N	ture) 1d) tion) on-Cr	itical Going	g High)	
E	- Header - Body - Event Message Re - Sensor Type - Sensor Number - Event Type - Event Direction - Offset - Byte 2 Encoding	vision		0x04 0x01 0x02 0x01 0x01 0x07 0x07	(4) (Tempera (2) (Thresho (Deasser (Upper N (Trigger	ture) ld) tion) on-Cr Read	itical Going	g High)	
	- Header - Body - Event Message Re - Sensor Type - Sensor Number - Event Type - Event Direction - Offset - Byte 2 Encoding - Byte 3 Encoding	vision	: : : : : : : : : : : : : : : : : : : :	0x04 0x01 0x02 0x01 0x01 0x07 0x07 0x01	(4) (Tempera (2) (Deasser (Upper N (Trigger (Trigger	ture) ld) tion) on-Cr Read Valu	itical Going ing) e)	g High)	
	- Header - Body - Event Message Re - Sensor Type - Sensor Number - Event Type - Event Direction - Offset - Byte 2 Encoding - Byte 3 Encoding - Reading	vision		0x04 0x01 0x02 0x01 0x01 0x07 0x01 0x01 0x01	(4) (Tempera (2) (Thresho (Deasser (Upper N (Trigger (Trigger (49)	ture) ld) tion) on-Cr Read Valu	itical Going ing) e)	g High)	
	- Header - Body - Event Message Re - Sensor Type - Sensor Number - Event Type - Event Direction - Offset - Byte 2 Encoding - Byte 3 Encoding - Reading - Threshold	vision		0x04 0x01 0x02 0x01 0x01 0x07 0x01 0x01 0x31 0x32	(4) (Tempera (2) (Thresho (Deasser (Upper N (Trigger (49) (50)	ture) ld) tion) on-Cr Read Valu	itical Going ing) e)	g High)	
	- Header - Body - Event Message Re - Sensor Type - Sensor Number - Event Type - Event Direction - Offset - Byte 2 Encoding - Byte 3 Encoding - Reading - Threshold	vision		0x04 0x01 0x02 0x01 0x01 0x01 0x01 0x31 0x32	(4) (Tempera (2) (Deasser (Upper N (Trigger (Trigger (49) (50)	ture) ld) tion) on-Cr Read Valu	itical Going ing) e)	g High)	
0x20 0	- Header - Body - Event Message Re - Sensor Type - Sensor Number - Event Type - Event Direction - Offset - Byte 2 Encoding - Byte 3 Encoding - Reading - Threshold - Threshold	vision 0x2 0x81 (: : : : : : : : :	0x04 0x01 0x02 0x01 0x01 0x01 0x01 0x31 0x32	(4) (Tempera (2) (Thresho (Deasser (Upper N (Trigger (Trigger (49) (50)	ture) ld) tion) on-Cr Read Valu	itical Going ing) e)	g High)	
0x20 0	- Header - Body - Event Message Re - Sensor Type - Sensor Number - Event Type - Event Direction - Offset - Byte 2 Encoding - Byte 3 Encoding - Reading - Threshold x10 0xd0 0x88 0x9 0x2 0x4 0x1	vision	: : : : : : :	0x04 0x01 0x02 0x01 0x01 0x01 0x31 0x32	(4) (Tempera (2) (Dressor (Upper N (Trigger (49) (50) 0x2b	ture) ld) tion) on-Cr Read Valu	itical Going ing) e)	g High)	

For VT027 Development with Four Slot AMC Simulation:

With the VT027 evaluation and development option, the ATC001 has a total of six NXP LPC2138's: two on-board (representing the VT027 design) and four in sockets to simulate the four out of eight AMC slots (representing the VT026 design). These four are loaded with VadaTech VT026 code (VT026 is a single LPC2138 running the IPMI code as an AMC module). The sockets can also be used to program the LPC2138's. The board has on-board switches to simulate the insertion and extraction of the AMC modules as well as the front panel switch for the AMC. The VT027 option is capable of communicating with the payload via I2C or RS-232.





For VT028 Development:

With the VT028 evaluation and development option, the ATC001 has a single NXP LPC2138. The VT028 is targeted for the ATCA modules that do not have any AMC slots. The VT028 option is capable of communicating with the payload via I2C or RS-232.

FIGURE 5: ATCOO1 Functional Block Diagram for VTO28 Development option





FIGURE 6: ATCOO1 option load for VTO27 Development

ORDERING OPTIONS

A = Built Option

- 1 = Protocol Analyzer
- 2 = VT027 Development
- 3 = VT028 Development

ATC001 - A00 - 000 - 00J

J = Conformal Coating

- 0 = None 1 = Humiseal 1A33 Polyurethane
- 2 = Humiseal 1B31 Acrylic



Document No_

_ Date:. August 27 2007